

VITO MINI BASE

Remote Function and Memory Function

REMOTE FUNCTIONS

1. Head Up
2. Foot Up
3. Head Down
4. Foot Down
5. Memory Position
6. Flashlight
7. Flat Position



SET UP MEMORY POSITION

1. Adjust the bed into desired position.
2. Press and hold “Memory” button ⑤ for 4 seconds, until hear a beep and backlight start flashing, then the current position of the bed is now saved as a Memory position

VITO MINI BASE

Syncing Instruction

To Sync Remote With the Base

1. Fit 2 AAA Batteries to the hand control.
2. Connect power to the transformer.
3. Press the “Head Down” ③ and “Foot Up” ② buttons on the remote and the pair button* connected with the control box simultaneously.
4. Once hearing a beep, the base and remote control are paired successfully



* The Pair Button

- The pair button is connected to the control box. You can locate the pair button through the power cable in between the transformer and control box.
- The pair button also has “return base to flat” function.

VITO LEISURE BASE

Remote Function and Memory Function

REMOTE FUNCTIONS

1. Head Up
2. Head Down
3. Foot Up
4. Foot Down
5. Memory Position 1
6. Memory Position 2
7. Flashlight
8. Flat Position

SET UP MEMORY POSITION

1. Adjust the bed into desired position.
2. Press and hold "P1" or "P2" button (⑤ or ⑥) for 4 seconds, until hear a beep and backlight start flashing, then the current position of the bed is now saved as a Memory position



VITO LEISURE BASE

Syncing Instruction

To Sync Remote With the Base

1. Fit 2 AAA Batteries to the hand control.
2. Connect power to the transformer.
3. Press the “Head Down” ② and “Foot Up” ③ buttons on the remote and the pair button* connected with the control box simultaneously.
4. Once hearing a beep, the base and remote control are paired successfully



















* The Pair Button

- The pair button is connected to the control box. You can locate the pair button through the power cable in between the transformer and control box.
- The pair button also has “return base to flat” function.

VITO COMFORT BASE

Remote Functions

REMOTE FUNCTIONS

1.  TV Position
2.  Anti-Snore Position
3.  Zero Gravity Position
4.  Head Up
Head Down
5.  Head & Foot Up
6.  Head & Foot Down
7.  Foot Up
Foot Down
8.  Memory Positions
9.  Set for 10 Min Massage
10.  Set for 20 Min Massage
11.  Head Massage On, Change intensity and Off
12.  Flat Position
13.  Foot Massage On, Change intensity and Off
14.  Massage On, Set Massage for 10min, 20 min, 30min and Off
15.  Flashlight
16.  Massage Mode



VITO COMFORT BASE

Syncing Instruction

To Sync ONE base ONLY

1. Fit 2 AAA Batteries to the hand control.
2. Connect power to the transformer.
3. Press the “Head Down” and “Foot Up” buttons on the remote and the pair button* connected with the control box simultaneously.
4. Once hearing a beep, the base and remote control are paired successfully

To Sync TWO bases to ONE remote

1. Chose the one to be used as the primary operating remote control and the other one as secondary remote control.
2. Press the “Head Down” and “Foot Down” buttons simultaneously on the **SECONDARY REMOTE**. The flashlight will turn on showing it is in pairing mode.
3. Within 10s of completing Step 2, press the “Head Down” and “Foot Up” button at the same time on the **PRIMARY REMOTE**.
4. If flashlight on the secondary remote starts flashing, the pairing is successful.



To Remove Sync of Two Bases

1. Press the “Head & Foot Up” and “Head & Foot Down” buttons simultaneously on the **SECONDARY REMOTE**.
2. If the flashlight is turned on, the sync of the secondary remote has been removed. The bed will go back to operating independently.

VITO COMFORT BASE

Reprogramming and Memory Function

STEPS OF REPROGRAMMING

PRESET POSITION

1. Adjust the bed into desired position.
2. Choose the pre-set position that you would like to change (TV, ZG or Anti-snoring).
3. Press and hold the chosen pre-set button for 3 seconds, until the backlight start flashing, then the current position of the bed is now saved as a custom position under the pre-set button.

SET UP MEMORY POSITION

1. Adjust the bed into desired position.
2. Press and hold “M1” (or “M2”, “M3”) button for 3 seconds, until the backlight start flashing, then the current position of the bed is now saved as a Memory position

